

# abi Prado Screen & ABIREMOTE1 Remote Control Manual Wall Switch Instructions

In addition to the normal RF, IR & 12V Relay controls, the **abi** Prado Screen (with built in remote receiver) and the Abiremote1 wall remote receiver can also be controlled with a wall switch, for Up & Down ONLY (Stop doesn't work). Connection is via the JP1 (RJ12) socket on the Abiremote1 & the same JP1 socket on the Prado receiver (see pics below). An RJ12 cable is supplied & connections as below.



Prado  
Receiver

JP1 Socket



Abiremote1

The Prado screen was not designed for manual control so to install the manual wall switch cable, a small hole has to be drilled in the back of the right end cover to fit the cable through. Remove the 2 screws holding on the cover & ensure you drill the hole so the cable can be pushed through without interfering with the existing Receiver.

To connect the RJ12 cable to the wall switch, connect:

- the BLACK wire to the Down (D) terminal.
- the GREEN wire to the Common (C) terminal.
- the WHITE wire to the Up (U) terminal.

The other 3 wires are not used.

Contact ABI on 02.9938 6866 with any queries.