



a brighter IMAGE Pty Ltd A.C.N. 086 389 942

For technical enquiries, phone 02.9938 6866

Email: info@abimage.com.au

LecternPro LB100/200 Instructions

Your LB100/200 Lectern is composed of 4 main components:

- # Main upright
- # Top Platen
- # 2 Feet

In addition, wrapped inside the hinged lid of the Platen, you will find:

- # Plastic bag containing 8 long bolts, 4 wing bolts, and 12 washers

To assemble the lectern:

1. Bolt the 2 feet to the bottom (square cut edge) of the upright panel using the 8 long bolts with washers.
2. Stand the lectern on the feet, and carefully place the top in position (hold it as the top of the lectern upright is sloping). Fix into position with the 4 wing bolts and washers.
3. The top Platen has 3 pre-drilled holes covered with plastic plugs, provided in case you want to add microphone or light fittings at some stage in the future.

If you have any technical enquiries, contact your local supplier or contact our technical help desk on the number listed above.