Instruction Sheet - LE Model Tables Models LE-26 and LE-27 Two Shelf Mobile Tables Models LE-34, LE-40, LE-42, LE-48 and LE-54 Three Shelf Mobile Tables

Z.V LUXOR

Customer Service Dept 2245 Delany Rd Waukegan, IL 60087 Ph: 847/244-1800 • 800/323-4656 Fax: 847/244-1818 • 800/327-1698



LE - Two Shelf Model



LE - Three Shelf Model

FOR BIG WHEEL

PARTS LIST

Models LE26 & LE27

- 1 Bottom shelf with casters sockets
- 1 Top shelf with handle
- 4 Long legs
- 4 Casters (2 w/brake)
- 1 Plug housing cover
- 2 Sheet metal screws

Optional Electric Assembly:

- 1 Electric cord
- 1 Power cord retaining bracket
- 1 Cord tie
- 3 Sheet metal screws

Models LE34, LE40, LE42, LE48 & LE54


- 1 Bottom shelf with casters sockets
- 1 Top shelf with handle
- 1 Center shelf with eight leg posts
 - 4 Short legs
 - 4 Long legs
- 4 Casters (2 w/brake)
- 1 Plua housing cover
- 2 Sheet metal screws


Tools Required:

- 1 Rubber Mallet
- 1 Slotted Screwdriver

IMPORTANT:

If your LE table does not have the Optional Electrical Assembly start by closing the electric plug housing in the handle of the top shelf as illustrated. If your LE table has the Optional Electric Assembly, see assembly instructions below. Start by assembling electric.





CORD MANAGEMENT TIE
TIE IS IN SECURED
POSITION


CORD RETAINING

TRACK #1

Firmly seat electrical assembly 3 plug unit into handle plug housing as illustrated. Secure with power cord plug retaining bracket. Thread cord through cord retaining track and out the opening in the side of the handle.


2

Secure power cord management tie into starter hole with sheet metal screws. See illustration A. Secure with power cord management tie by wrapping tie around cord and fastening. Cut off any unnecessary extra length of tie.




For safety and neat appearance secure cord plug to cord by utilizing plug snap.


Models LP-26 and LP-27



Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 legs onto leg posts.




Position bottom shelf, ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.



Push the four casters firmly into the holes in each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LP table right side up. It is now ready for use.

Models LE-34, LE-40, LE-42, LE-48 and LE-54


*Models LE34 and LE40 use short legs first.
*Models LE42, LE48 and LE54 use long legs first.




Models LE-34 and LP-40: Lay top shelf (with handle) ribbed side up on a smooth surface. Push all 4 short legs onto leg posts.

Models LE-42, LE-48 and LE-54: Lay top


shelf (with handle) ribbed side up on a smooth surface. Push all 4 long legs onto leg posts.




Position center shelf (with 8 leg posts) ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer center shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.



Push remaining 4 legs into leg posts of center shelf.



Position bottom shelf, ribbed side up, over the 4 legs and insert leg posts into legs. Using a rubber mallet, firmly hammer bottom shelf into legs until all 4 legs are seated (flush) against the surfaces of both shelves.



Push the four casters firmly into the holes in each corner of the bottom shelf. Important: Casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your LE table right side up. It is now ready for use.

Instruction Sheet - Endura Mobile Cabinet Tables Instructions for LE-C Units with locking Cabinet Models LE26C, LE27C

Customer Service Department

Luxor

2245 Delany Road Waukegan, IL 60087

Ph: 847/244-1800 • 800/323-4656 Fax: 847/244-1818 • 800/327-1698



PARTS LIST

Models LE27C, LE26C

- 1 Top shelf w/handle
- 1 Bottom shelf w/caster sockets
- 4 Leas
- 2 Cabinet side panels
- 1 Back Panel
- 1 Door in frame
- 1 Power cord
- 4 Casters 2 with brake
- 8 1 3/4" machine screws


Tools Required:


Rubber mallet

- 1 Grommet Cap
 - 1 Cord guide cover
 - 2 Grommet rings
 - 1 Rubber Band
- 4 Small 'U" brackets
- 1 Large "U" bracket
- 1 Cord wrap bracket
- 2 Stove bolts


If you did not get an electric assembly with your cart start by closing the electric plug housing in the handle of the top

shelf as illustrated below.







With bottom shelf facing up push all four legs onto leg posts. Using rubber mallet hammer legs firmly into position. Legs must be seated (flush) against the shelf surface. Place rubber band around legs to aid in the assembly of cabinet side panels and doors.




Install the side panels first. Slide panels down between legs until they are nested inside the shelf lip and flush against the shelf surface. Rubber band will hold legs and side panels in place while installing back panel and front door.




Install the back panel in the same manner as side panels. Install grommet ring into grommet hole. Insert two stove bolts as illustrated through "U" bracket into back panel and through slots in cord wrap bracket. Align the cord wrap bracket onto stove bolts from the outside of back panel, and secure with two kep nuts.




Press 3-outlet power cord into "U" bracket and feed remaining cord through grommet hole and wrap remaining cord around cord wrap bracket. For safety and neat appearance, secure cord plug to cord with plug snap.




Install door panel same as back panel with door handle at top. Be sure door opens outward and door frame is also placed between legs and nested flush on the shelf floor.



Begin seating of top shelf by holding door panel, leg and side panel as illustrated. Gently tap corner posts into legs until all posts are partially inserted into legs. Repeat hammering action more firmly going around to each corner, being certain that each panel nests inside the lip of the top shelf. Repeat this action until top shelf is fully nested.



Install grommet ring and grommet cap into top shelf. For tables with electric assembly, snap off cord guide cover from grommet cap to allow equipment plug entry. Insert grommet cap into grommet ring.



Push the four casters firmly into the holes in each corner of the bottom shelf. Important: casters must be fully seated. Tap firmly with rubber



Instruction Sheet - Endura Mobile Cabinet Tables Models LE-34C, LE-40C, LE-42C, LE-48C and LE-54C



Customer Service Department Luxor 2245 Delany Road Waukegan, IL 60087

Ph: 847/244-1800 • 800/323-4656 Fax: 847/244-1818 • 800/327-1698







PARTS LIST

Models LE-34C, LE-40C, LE-42C, LE-48C, LE-54C

- 1 Top shelf w/handle
- 1 Center shelf w/eight leg posts
- 1 bottom shelf w/caster sockets
- 4 Short leas
- 4 Long legs
- 2 Cabinet side panels
- 1 Back panel
- 4 Casters 2 with brake

Tools Required:

Rubber mallet

- 1 Door in frame
- 1 Grommet cap
- 1 Cord guide cover
- 1 Grommet ring
- 1 Rubber band

IMPORTANT The electrical unit should be assembled first.


If your Endura Cabinet Table does not have the Electrical Assembly and Cable-Track™ Cord Management System, start by closing the electrical plug housing in the handle of the top shelf as illustrated below.

Units with electric receive following parts:


- 1- Cord guide cover
- 1- Cord wrap
- 4- Cord ties 1- L-bracket
- 6- Screws
- 1- Power cord

Units without electric receive following parts:


- 1- Cord guide cover
- 2- Screws
- 1- Plug housing cover




With bottom shelf facing up push all four 18" legs onto leg posts. Using rubber mallet hammer legs firmly into position. Legs must be seated (flush) against the shelf surface. Place rubber band around legs to aid in the assembly of cabinet side panels and doors



Install the side panels first. Slide panels down between legs until they are nested inside the shelf lip and flush against the shelf surface. Rubber band will hold legs and side panels in place while installing back panel and front door.




Install the back panel in the same manner as shown in Step #3. NOTE: Cabling hole in back panel should be toward the top.




NOTE: Models LE-40C, LE-48C, and LE-54C

Install door panel same as back panel, with door handle at top.




Begin seating of center shelf by holding door panel, leg and side panel as illustrated. Gently tap corner post into leg. Repeat on all 4 sides until all posts are partially inserted into legs. Now repeat hammering action more firmly going around to each shelf post and driving the leg posts more securely into the legs.

Top of panels and door frame must be nested into the underside of the center shelf lip in the same manner as the bottom shelf.



Push remaining 4 legs onto center shelf posts as illustrated. Place top shelf (with handle) onto legs. Insert leg posts into legs of top shelf. Using rubber mallet, firmly hammer top shelf into legs until all four legs are seated against shelf surface. install grommet ring and grommet cap into top of shelf. For tables with electric assembly, snap off cord guide cover form grommet cap to allow equipment plug to be run through grommet. Insert grommet cap into grommet ring. Remove rubber band.



Push the four casters firmly into the holes in each corner of the bottom shelf. Important: casters must be fully seated. Tap firmly with rubber mallet to properly seat casters. Turn your Endura Table right side up.





